


FrameWorx Banner Display Series

Product Parts

- 1 - Bottom Ends
- 2 - Top Poles
- 3 - Sides Poles
- 4 - Support Pole (on 8' & 10')
- 5 - Graphic



*quantity of each part differs by size of display



Display Set-Up

Step 1

Begin by removing all parts from the carry case and place on a clean, flat surface. Ensure you have all the components listed above.

Step 2


Start by laying out Bottom Ends (1) and extend out feet.



Step 3

Connect Bottom Ends (1) by screw knob, pushing ends together and inserting knob through the provided hole.


****Models less than 30" wide can skip this step***



*do not over tighten

Step 4


Continue to connect frame by connecting poles by their associated numbers. Larger displays come with a support pole that is inserted through the middle of the display (as shown below)



FrameWorx ... continued

Step 5

To attach Graphic (5), place grommets over the hooks in the corners of the display. Firmly grasp hook at end where it attaches to spring to avoid stress on plastic hook.



*each hook comes with two bracket so it can incorporate a banner for the front and back.




8.5' & 10.5' banners are only offered in No Curl Fabric

*graphics are available in three different materials,
- Aluminum Fabric
- No Curl Opaque Fabric
- 13oz Smooth Vinyl (single or double sided)

Sizing Chart

FrameWorx Series comes in many different shapes and sizes.



Storage & Care

Place all product parts into Carry Case and store in a cool dry location. Recommended for indoor use only.